



1. Visit Protectowrap.com for the most current information
2. Refer to Technical Data sheet for more information
3. Protecto Wrap Underlayments should be installed to form water-shedding laps
4. PW 100-40 AVB turned up wall 6", turned down deck edge as required
5. Primer recommended on all substrates if adhesive is marginal
6. Metal surfaces may need to be solvent wiped and/or abraded to achieve optimum adhesion

JIFFY DECK SYSTEM



EFFECTIVE DATE: 07/13/09
 SUPERSEDES:
 SCALE: NOT TO SCALE
 DRAWING: PW102