



1. Visit Protectowrap.com for the most current information
2. Refer to Technical Data sheet for more information
3. Protecto Wrap Underlayments should be installed to form water-shedding laps
4. Install Protecto Wrap products in order as shown by numbers
5. Score and fold Weather Resistive Barrier above header to allow Protecto Wrap Products to be installed
6. Install head flashing under Weather Resistive Barrier; Mechanically fasten as necessary
7. Fold Weather Resistive Barrier back over head flashing and seal edges

EXTERIOR SLIDING DOOR WITH
DECK FLASHING INSTALLATION
AFTER WEATHER RESISTIVE
BARRIER



EFFECTIVE DATE: 02/13/10

SUPERSEDES:

SCALE: NOT TO SCALE

DRAWING: PW-201