



1. Visit Protectowrap.com for the most current information
2. Refer to Technical Data sheet for more information
3. Protecto Wrap Underlayments should be installed to form water-shedding laps
4. All surfaces must be clean, dry, free of dirt and other foreign materials.
5. Cut a piece of Protecto Premium Dual Guard Threshold Tape the length of the threshold opening extending approximately 1" minimum up the sides of the door jam.
6. Peel off release liner and begin applying Protecto Premium Dual Guard Threshold Tape to the door sill plate by smoothing as the adhesive comes into contact with the door sill.
7. Place the threshold over the Protecto Premium Dual Guard Threshold Tape and secure.

EXTERIOR DOOR SILL CROSS SECTION SHOWING
PROTECTO PREMIUM DUAL
GUARD THRESHOLD TAPE



EFFECTIVE DATE: 02/03/10
SUPERSEDES:
SCALE: NOT TO SCALE
DRAWING: PW202