



- 1. Visit Protectowrap.com for the most current information**
- 2. Refer to Technical Data sheet for more information**
- 3. Protecto Wrap Underlayments should be installed to form water-shedding laps**
- 4. All surfaces must be clean, dry, free of dirt and other foreign materials.**
- 5. Cut a piece of Protecto Premium Dual Guard Threshold Tape the length of the threshold opening extending approximately 1" minimum up the sides of the door jam.**
- 6. Peel off release liner and begin applying Protecto Premium Dual Guard Threshold Tape to the door sill plate by smoothing as the adhesive comes into contact with the door sill.**
- 7. Place the threshold over the Protecto Premium Dual Guard Threshold Tape and secure.**

EXTERIOR DOOR SILL CROSS SECTION SHOWING
PROTECTO PREMIUM DUAL
GUARD THRESHOLD TAPE



EFFECTIVE DATE: 02/03/10
SUPERSEDES:
SCALE: NOT TO SCALE
DRAWING: PW203