

- 1. Visit Protectowrap.com for the most current information
- 2. Refer to Technical Data sheet for more information
- 3. Protecto Wrap Underlayments should be installed to form water-shedding laps
- 4. All surfaces must be clean, dry, free of dirt and other foreign materials.

WOOD SILL PLATE
PROTECTO ENERGY PLATE LINER



EFFECTIVE DATE: 02/27/10

**SUPERSEDES:** 

SCALE: NOT TO SCALE DRAWING: PW305