

- 1. Visit Protectowrap.com for the most current information
- 2. Refer to Technical Data sheet for more information
- 3. Protecto Wrap Underlayments should be installed to form water-shedding laps
- 4. If Protecto Deck ACQ Flashing Tape is to be exposed to UV, Protecto Deck ACQ Flashing Tape should be trimmed flush to galvanized conector to prevent UV exposure

CORROSION RESISTANCE FOR GALVANIZED CONNECTORS AT COLUMN/POST BASE PROTECTO DECK ACQ FLASHING TAPE



EFFECTIVE DATE: 02/13/10

SUPERSEDES:

SCALE: NOT TO SCALE

DRAWING: PW310