



1. Visit Protectowrap.com for the most current information
2. Refer to Technical Data sheet for more information
3. Protecto Wrap Underlayments should be installed to form water-shedding laps
4. Edge laps are minimum 2" and end laps are minimum 6"- Refer to Technical Data Sheet for Product specific requirements
5. Install Protecto Wrap Underlayment, Detail Tape, and JS 160 H Mastic, in order shown
6. Extend Protecto Wrap Underlayment from eave to below Chimney, and from above Chimney to ridge
7. Determine if Chimney materials (mortar, block, flashing, etc.) are compatible with Protecto Wrap Underlayments

CHIMNEY



EFFECTIVE DATE: 01/07/10
 SUPERSEDES: 07/07/09
 SCALE: NOT TO SCALE
 DRAWING: PW404