



1. Valleys require a minimum 18" wide roll centered down the full length of the valley
2. Install Membrane starting at the lowest point of roof slope and work up the slope
3. Protecto Wrap Underlayments should be installed to form water-shedding laps
4. Install in order as shown by numbers
5. Refer to Technical Data sheet for more information
6. Visit Protectowrap.com for the most current information

VALLEY FLASHING DETAIL



Premium Building Products
That Protect

EFFECTIVE DATE: 08/25/10

SUPERSEDES:

SCALE: NOT TO SCALE

DRAWING: PW406