



1. Visit [Protectowrap.com](http://Protectowrap.com) for the most current information
2. Refer to Technical Data sheet for more information
3. Install Protecto Wrap products in order shown
4. Check local building codes for weather resistive barrier requirements and install Protecto Wrap Products to form water-shedding laps
5. If applicable, leave release paper on lower half of sill flashing, for future tie-in

<b>FLANGED WINDOW</b> BEFORE WEATHER RESISTIVE BARRIER IS INSTALLED <b>PROTECTO WRAP</b> <b>SILL DRAINAGE SYSTEM</b>	 Premium Building Products That Protect	EFFECTIVE DATE: 01/13/10
		SUPERSEDES: 09/03/09
		SCALE: NOT TO SCALE
		DRAWING: PW602