



1. Visit Protectowrap.com for the most current information
2. Refer to Technical Data sheet for more information
3. Check local building codes for weather resistive barrier requirements
4. Remove WRB from top of sill plate
5. Install Protecto Wrap products in order shown
6. Install Protecto Wrap Products to form water-shedding laps
7. If applicable, leave release paper on lower half of sill flashing, for future tie-in

MECHANICALLY FASTEN AS NECESSARY IN CORNERS THROUGH PROTECTO WRAP MEMBRANE

WRB

- A. Cut, fold up and temporarily secure weather resistive barrier above header, and down sides, to allow for flashing installation
- B. Install Protecto Wrap Membrane under WRB along header, and down sides
- C. Fold WRB back over head flashing and side flashing, and seal with tape, as shown

FLANGED WINDOW
 AFTER WEATHER RESISTANT BARRIER IS INSTALLED
 PROTECTO WRAP
 SELF ADHERED FLASHING



EFFECTIVE DATE: 01/08/10
 SUPERSEDES: 11/08/09
 SCALE: NOT TO SCALE
 DRAWING: PW603