


1. Visit [Protectowrap.com](http://Protectowrap.com) for the most current information
2. Refer to Technical Data sheet for more information
3. Install Protecto Wrap products in order shown
4. Check local building codes for weather resistive barrier requirements and install Protecto Wrap Products to form water-shedding laps
5. If applicable, leave release paper on lower half of sill flashing, for future tie-in
6. Add continuous air seal around perimeter using backer rod and sealant, or low pressure minimal expanding foam
7. Sealant used shall be compatible with Protecto Wrap membranes, see Technical Letter "Chemical Compatibility" for more information

<p>FLANGED WINDOW PROTECTO WRAP EXTREME EXPOSURE SILL DRAINAGE SYSTEM</p>	 <p>Premium Building Products That Protect</p>	<p>EFFECTIVE DATE: 09/03/09 SUPERSEDES: SCALE: NOT TO SCALE DRAWING: PW604</p>
---	---	--