



1. Visit [Protectowrap.com](http://Protectowrap.com) for the most current information
2. Refer to Technical Data sheet for more information
3. Install Protecto Wrap products in order shown
4. Check local building codes for weather resistive barrier requirements and install Protecto Wrap Products to form water-shedding laps
5. If applicable, leave release paper on lower half of sill flashing, for future tie-in
6. Mechanically fasten as necessary

HALF ROUND WINDOW  
 PROTECTO WRAP  
 PSDS



EFFECTIVE DATE: 01/08/10  
 SUPERSEDES: 09/03/09  
 SCALE: NOT TO SCALE  
 DRAWING: PW605