



# WHISPER MAT® LVT

LUXURY VINYL TILE  
SOUND CONTROL UNDERLAYMENT

30" x 80' ROLL

**JUST UNROLL  
AND APPLY LVT**

## PROPERTIES WHISPER MAT LVT

Green Approval CRI Green Label Plus Certified for Optimal Indoor Air Quality

Applications Residential & Commercial

Thickness 1.8 mm (70 mils)

Density 25 lb/ft<sup>3</sup>

Content 100% Virgin Latex Rubber

Substrates Non-Woven

Antimicrobial Protection Yes

Roll Width 30"

Roll Length 80 ft

Roll Weight 34 lbs

Rolls/Pallet 16

Pallets/Truck 26

Full Roll 200 sf

Color Green

Warranty 10 Year Limited Warranty

## APPROVED SUBSTRATES

- Completely Cured Concrete
- Interior Plywood
- Cement Backer Units
- Properly Prepared OSB

## SOUND RATINGS

### Luxury vinyl tiles and planks

- 6" Concrete Floor With No Ceiling – IIC 57, STC 51
- 6" Concrete Floor With Ceiling Assembly – IIC 73, STC 63
- Delta IIC 27

## LEED® POINT CATEGORIES

- 100% Post-Consumer Recyclable
- Acoustical Properties - LEED® IEQp3
- Low Emitting Materials - LEED® EQ4.3
- Regional Priority - LEED® MRc5.1, 5.2I

## APPROVED FOR USE UNDER

Laminate and Luxury Vinyl Tiles & Planks

## INSTALLATION METHODS

Float, Single Glue, Double Glue

## SPECIFICATIONS

Material Composition: Rubber

Compression Set: ASTM D 1055-97 (22h, 70C) – 16%

Indentation: ASTM F1914 – 12%

Smoke Density: ASTM A662 – Less Than 89 Max

Flammability Test: ASTM D 2859(DOC FF 1-70) – Pass

Thermal Resistance: 0.205  
(R-Value)

Indoor Air Quality: CRI Certified For Low Emitting Materials



**EASY APPLICATION  
FOR QUICK  
INSTALLATION**



# WHISPER MAT® LVT

## LUXURY VINYL TILE

### SOUND CONTROL UNDERLAYMENT

**FLOORING PRODUCTS:** Laminate and Luxury Vinyl Tiles & Planks

#### Floor Prep

Substrate must be level, clean and dry with no protruding nails or staples. Substrate must be checked for excessive moisture. If substrate moisture/vapor is beyond 4lb. emissions or an RH level of more than 75% of slab, these conditions must be mitigated prior to Whisper Mat LVT installation. Leveling cements must be completely dry before membrane application.

ACCLIMATE UNDERLAYMENT FOR A MINIMUM OF 24 HOURS PRIOR TO INSTALLATION.

#### Floating Installation

1. Roll out underlayment parallel to the wall, in the opposite direction the floor covering will be installed.
2. Trim the underlayment to fit the sub-floor, leaving a ¼" gap at each wall.
3. Unroll the pre-cut underlayment. Smooth underlayment as you go to remove any wrinkles or air pockets.
4. Roll out the next section of underlayment in the same manner making sure the seams are butted together but not overlapping.
5. Install the floor covering according to the manufacturer's guidelines.

#### Glue Installation

1. Roll out underlayment parallel to the wall, in the opposite direction the floor covering will be installed.
2. Trim the underlayment to fit the substrate, leaving a ¼" gap at each wall.
3. Unroll the pre-cut underlayment. Smooth underlayment as you go to remove any wrinkles or air pockets.
4. Roll out the next section of underlayment in the same manner making sure the seams are butted together but not overlapping.
5. Install the floor covering according to the manufacturer's installation instructions. Note: When installing vinyl flooring tiles or planks be sure to allow adhesive to become tacky to the touch before installation of flooring over underlayment. **DO NOT WET SET FLOORING PRODUCTS OVER UNDERLAYMENT.**

**DISCLAIMERS:** IN GLUE INSTALLATIONS PLEASE NOTE THAT THE UNDERLAYMENT IS NOT DESIGNED TO COUNTERACT FLOORING MATERIAL MOVEMENT OR CHANGES IN WIDTH OR LENGTH DUE TO TEMPERATURE FLUCTUATIONS OUTSIDE THE SPECIFIED ACCEPTABLE RANGE OF THE FLOORING MANUFACTURERS. ANY CLAIMS RESULTING FROM CUPPING, PEAKING, WARPING OR OTHER DEFORMATION OF FLOORING PLANKS OR TILES WILL NOT BE APPROVED OR ACCEPTED BY PROTECTO WRAP COMPANY.

DO NOT WET SET FLOORING MATERIALS INTO ADHESIVE. BE SURE TO ALLOW THE ADHESIVE TO PROPERLY FLASH AND BECOME TACKY TO THE TOUCH BEFORE APPLICATION OR FAILURES COULD RESULT SUCH AS SEPERATION OF THE PLANKS OR TILES, CUPPING, PEAKING OR OTHERWISE.

ONLY APPROVED AND TESTED ADHESIVES SHOULD BE USED.

#### Approved Adhesives For:

Laminate and luxury vinyl tiles and planks

- MAPEI
  - EC0360
  - G90
- ROBERTS
  - 6300
- FRANKLIN
  - TITEBOND 670
  - TITEBOND 811
- BOSTIK
  - BEST FLOORING ADHESIVE
  - GREENFORCE
- STAUFF
  - D-737
- TEC
  - 744 SOLID VINYL PLANK AND TILE ADHESIVE
  - 752 PREMIUM TRANSITIONAL VINYL ADHESIVE
  - FLEXERA HT
- PARABOND 5092 HT
- EC0373
- G21
- TITEBOND 771-STEP
- EFA
- GREEN FUSION
- D764



1955 South Cherokee Street  
Denver, CO 80223  
(800) 759-9727  
www.ProtectoWrap.com

WLVN-200 (3-23)