

## TECHNICAL LETTER

Protecto Wall VP

Addressing Overlaps for Extended Exposure and Cold Weather Applications

Per the Installation Instructions, Protecto Wall VP is to be installed over clean and dry substrates and firmly rolled with a 2 handed roller during the installation process. The aggressive nature of the Super Stick adhesive allows for installation without the need for Primer including cold weather applications.

Properly installed and rolled Protecto Wall VP adheres well to itself. However, additional attention is recommended to the overlaps for circumstances where extreme conditions of extended exposure or cold weather are anticipated.

Protection of the overlaps can be accomplished by applying Super Stick Flashing over the overlaps or enhanced adhesion can be accomplished by using one of the accessory Primers listed in the Instructions under the overlaps.

Protecto Wall is to be covered within 180 Days of installation.

Refer to www.protectowrap.com for additional information on Protecto Wall VP.

Rocky Hill Protecto Wrap Technical Manager March 12, 2024