

WATERPROOF SOUND CONTROL

Water Resistant and Waterproof Applications with Whisper Mat[®] CS



WATER RESISTANT APPLICATIONS

Apply the Protecto Wrap No. 6000 Primer to the subfloor and allow to dry (approximately 30 minutes) before installing the Whisper Mat CS to ensure a good bond. Install Whisper Mat CS and align membrane in a butt joint fashion with a maximum of 1/4" gap, making sure not to overlap seams. Apply a generous coat of PROTECTO LIQUID MEMBRANE liquid approximately 4" wide over all seams of the Whisper Mat CS membrane and allow to dry. Product is cured when the color turns to black. Once dry apply a second coat of PROTECTO LIQUID MEMBRANE.

When the 2nd coat turns black (approximately 1 - 2 Hours weather dependent), tile may be installed using approved Latex Portland Cement Mortars.

Option: If additional water resistant protection is desired at the perimeter walls, apply PROTECTO LIQUID MEMBRANE with Reinforcing Fabric as described below.

WATERPROOF APPLICATIONS

For applications requiring ANSI 118.10 waterproofing, apply a generous coat of PROTECTO LIQUID MEMBRANE approximately 4" to the perimeter of subfloor and 4" up the wall. Embed a (7 1/2") sheet of reinforcing fabric into the wet liquid compound so that it bleeds through fabric. Next, apply another coat on top of fabric so that fabric is completely covered. Apply 2 coats of PROTECTO LIQUID MEMBRANE to the entire subfloor, each coat may be applied by brush or heavy nap paint roller to a 24MIL thickness (wet) and allow dry to the touch, apply a final coat of PROTECTO LIQUID MEMBRANE to entire surface within 24 hours to seal the installation. Once entire installation turns black and is dry to the touch (approximately 1 - 2 hours), apply the Protecto Wrap No. 6000 Primer to the subfloor and allow to dry (approximately 30 minutes) before installing the Whisper Mat CS to ensure a good bond. Install Whisper Mat CS, and align membrane in a butt joint fashion making sure not to overlap seams. Apply a generous coat of PROTECTO LIQUID MEMBRANE approximately 4" wide over all seams of the Whisper Mat CS membrane and allow to dry. Product is cured when it turns black.

The reverse of this application is also acceptable. Install the Whisper Mat CS to the subfloor with primer, install the floor to wall joint treatments as described above, and finish with 2 coats of PROTETO LIQUID MEMBRANE completely covering the Whisper Mat CS.

For further information refer to www.protectowrap.com for technical data.

| RESIDENTIAL • COMMERCIAL |

